



# Wireless receiver for control ofelectric heating devices - SOCKET MOUNTED -

۲

- Control of electric heating systems
- The connected electric appliance is switched according to the required temperature

۲

- Two-way radio communication at 433,92 MHz
- The control unit PH-BSP is the pilot component
- Component of the PocketHome® system



( )

Bedienungsanleitung Version 11.02 ۲


## INSTALATION AND ACTIVATION PROCEDURE

PH-SP2 is used for switching the heating device in connectionwith the PH-BSP control unit.

- 1. Connect receiver in 230V/50 Hz socket
- 2. The green diode flashes on the receiver: thus the receiver is ready for further setting.
- 3. Shortly press the FUNCTION BUTTON (see pic.2) for about 1.5 s (the green and red diode are flashing alternately).
- 4. On the PH-BSP control unit, press the"Test" button in the ACTIV mode to activate the SP switching components (see page 10 of the PH-BSP instructions).
- 5. If the code has been learned correctly, the green and red diodes flash simultaneously.

## FUNCTION BUTTON:

SHORT PRESSING - coding. LONG PRESSING (for about 5 s) - RESET deleting the code from the memory (the green and red LEDs flash simultaneously).



# **TECHNICAL PARAMETERS**

230 V/ 50 Hz
two-way
433,92 MHz
< - 95 dBm
200 m (in free area), 25 m (in built-up area)
relay, max.16A/ 250 VAC
IP40
0 to 40°C
109 mm x 80 mm x 31mm

### DECLARATION OF CONFORMITY

We, ELEKTROBOCK CZ s.r.o., herewith declare that our product PH-SP3 is in conformity with the basic requirements and other respective provisions of the directive 1999/5/ES. Issued: 1.09.2008



ELEKTROBOCK CZ s.r.o. Blanenská 1763 Kuřim 664 34 ELEKTROBOCK CZ Tel./fax: +420 541 230 216 www.elbock.cz

 $(\mathbf{O})$ 



stamp of shop: examined by:

CERTIFICATE OF GUARANTEE

(guarantee period for the product amounts to 2 years)

date of sale::

Send the product for guarantee and after guarantee service to manufacturer's address.



## INDICATION DIODES

LED 1	LED 2	FUNCTION	
		empty memory, code not learned	
		code learned	
		FLASHING ALTERNATELY= code learning mode FLASHING SIMULTANEOUSLY= code has been learned SIMULTANEOUS LONG FLASH= code was ERASED	
		relay switched	
		ERROR (if no signal is received from thetransmitter within approx. 6 hours, it switches tothe 2-min-ON / 8-min-OFF mode). LED flashes only if the relay is on, i.e. for 2 minutes.	

EXPLANATION:

product No.:

LIT 💭 UNLIT 🌘 FLASHING





